


SCIPY



500343

PÁG.
204

PIEZA N°	DESCRIPCIÓN	COD.	REF.	UD/CAJA
1	ASA SUPERIOR SCIPY	RSCP001	B.2052.05.001	1
2	SOPORTE ASA SCIPY	RSCP002	S.3012.13.001	1
3	TAPA ASA SCIPY	RSCP003	S.2052.14.001	1
4	TAPA FILTRO SCIPY	RSCP004	S.2052.14.003	1
5	CESTILLO FILTRANTE SCIPY	RSCP005	B.2052.09.002	1
6	RODILLO SCIPY	RSCP006	B.2052.04.001	1
7	RODAMIENTO RODILLO SCIPY	RSCP007	S.2052.10.001	1
8	CORREA TRANSMISIÓN T10 SCIPY	RSCP008	T.5.2.004	1
9	TAPA LATERAL 1 SCIPY	RSCP009	S.2052.13.001	1
10	TAPA LATERAL 2 SCIPY	RSCP010	S.2052.13.002	1
11	SOPORTE RODILLO SCIPY	RSCP011	S.2052.10.002	1
12	CORREA TRACCIÓN 162XL SCIPY	RSCP012	T.5.2.005	1
13+14+15+ 16+17+18+ 19+20+21+ 22+23	BLOQUE MOTOR SCIPY	RSCP026	-	1
24	ASA DESLIZANTE SCIPY	RSCP024	S.3012.14.001	1
25	CAJA CONTROL SCIPY	RSCP025	B.2052.07.001V1.0	1
25.1	TAPA INFERIRO CAJA CONTOL SCIPY	RSCP0251	S.0000.02.007	1
25.2	TARJETA ELECTRONICA CAJA DE CONTORL SCIPY	RSCP0252	D.2.01.2.008	1
25.3	PANEL DE CONTROL SCIPY	RSCP0253	S.0000.01.008	1
25.4	CARCASA CAJA DE CONTROL SCIPY	RSCP0254	D.2.06.024	1
25.5	CABLE CAJA CONTROL SCIPY	RSCP0255	D.2.05.001	1